



## **Throttle Position Sensor (TPS) Calibration**

Document Version	1	Release Date	25 November 2022
------------------	---	--------------	------------------

Application information	Generic
Vehicle	Not Applicable
Model	Not Applicable
Year of manufacture	Not Applicable

## Note:

- Read through all instructions before installation and use.
- Ensure that the bike is switched off and the key is out of the ignition before proceeding with the installation.
- Some parts of the bikes might be hot/sharp and cause burns/cuts. Proceed with extreme caution or wait until the bike has cooled down. Always wear safety gloves.
- When the installation is complete, ensure to secure the wiring loom away from the movable parts or components that tend to heat up during the normal operation of the vehicle at any chance.
- PowerTRONIC is intended for motorsport use on a closed course, please check with your local laws before using this product. Race Dynamics / PowerTRONIC is not liable for the consequences of using the product.

## Support:

North & South America	: +1 267 214 9292 (Call) +91 9606 044 178 (WhatsApp)
India, Bangladesh, Bhutan, Nepal & Sri Lanka	a : +91 9916 229 292 (Call & WhatsApp)
Rest of the world	: +91 9606 044 177 (Call & WhatsApp)
Email	: support@powertronicecu.com
Website	: www.powertronicECU.com



PowerTRONIC

**Throttle position sensor (TPS)** calibration would be required for the **PowerTRONIC** to optimally detect the throttle percentage. We recommend that you complete the throttle calibration after installing the **PowerTRONIC** for smoother running of the bike.

## **TPS Calibration Procedure**

- 1. Download and Install Powertronic R-Tune V4 software. (Refer R-Tune installation manual)
- **2.** With the PowerTRONIC connected to your bike, use the USB cable and connect it to a windows based PC through R-Tune Software.
- 3. Select the appropriate com port number. Refer to Figure below

=																			COM13 - U	ISB	
Po	ver	THU		J																5	9
eeff Table	Fuel1 t	able -																			
park 1 Table	Contraction of the local division of the loc	1208	10.00	3808	4200	1008	8088	1908	8089	****	10000	11090	13899	1.000	1480.0	15088	16249	119408	tadde	1211	38008
el 2 table		*																			
ant 2 labre		1			1					1											
		*			1	.0	1								1			0			
		1	6	0	- A.	0	- (e	1.1		0		0		. 0		0		0			
	Ro		10	2	1.5			1.0		15			1.1			18	1.5		- 25	190	
	122	1			20												÷.	0		1.0	÷.
	144.5			. 2	11			1.0	1				- 1	. e -	1		100	0 :		1962	
	286.				11	0	1.1	£.		0			1				1	0	- 10		8.
							1.4														
			- Ce - Ge	1.41			100	100	121	1.4	1.000						1000	80	1.0		
				1.0			1.4			1.0		· ·						*:			
				: e. :	- N.			*,/	*	.9							0.00	Ø.:	2.9	1.4.1	
		E.	4		A :-	2	(a	- 60	2	2		4	1	(e)	1	- 18	1	45	- 18	3 C	£ ::
	38	1	18	- 3	- X.		- 24	1.6		. 0				( #C	×		- F	0	- 36		
		1	٥		80	2	1.0			. 0	- e	α.			- ¥2		14			640	8
	10		2	- a.	10	÷.	- 54	1.63		3ê		÷.	- 14 - L	. 4		1.0	1.0	a)	- 12	1.943	10
	10		÷.		100		- 54	1.62	1 X	36		÷.	- 14	24°	1	- 16	141	0	14	1947	- 62
	141	i.		14	12		14	1.1					1				1			141	
	1														1	14					1
			1		20					14	1021							1		1	
		-			- 58		1	. N.		1				<u> </u>							1
		*			1.1		1	1.1	1	1.1			1.1		1.						

(To check your com port number, go to **Device Manager**, **Select Ports (COM & LPT)**, and note the number on the **Silicon labs CP210x USB to UART Bridge**. Refer to figure)





=																			COM13 -	USB	
	wer	THU		<u> </u>														c		5	a
Foell Table	Fuelt 1	able																			
ipark 1 Tabla		1800	2000	\$000	4555	5554	1000	TOOM	8095	9000	10000	11000	12000	15890	14000	15000	16260		TREEF	1900	0000
uel 2 table				100	0	a		0	0		•	0			D	0	0		2	-	•
park 2 labe				<u>8)</u>	8	a.		0	0	4	<u>8</u>	4	0	2	B	0	85	Refre	sh	Cor	inec
			0	65	0	α.		0	0	4	- E	0	0		0	0	0				0
		0	0	15	0	a	. 9	0	0	1	<u>.</u>	¢	0	3	¢ .	0	0		t	0	0
	10	0	5	10	0	α.	e	10	0	÷.	÷.	0	0	3	Ð	0	0	¥.	¢	ø	0
	22	. 9		12	8		18	. 8			5			2	· •			3.		<u>.</u> 8	
	100		5	10	0	a.	e	6	0	- 12 -	÷.	0	0		D.	0	0	1	÷		6
		.9		5	0	a		0	0	- E		0	0				۰.				. 9
	11	3	5	10	0	a.	- 19	0	0	10	- F.	0	0	6	0	0	6		τ	0	6
	- 50	. 9	0		0	a		0	.0			0	0		0	0	0		e		.0
				1	0	ir.		0	5	÷	÷.				p	0	0		e	i e	
				15	g :	σ.		0		1.5	10					0	0				
			,							,			0	,		0					,
				-										,							
				10		-	-							-			-			-	
				-						-		·									
			-	e	•	a			•		8	•		3	1.000	•	•				
		.0	•	- E -	0	a	10	0	0	- B.:	B.	0	0	3	0	0	6	10	2	<u></u>	- 0
	10	10	2	5		0		0	0	- E	8	.0	0	18	5.0	0	0			9	2
		0	0	- F	0	a		0	0	10	10	0	0	<u></u>	0	0	0	1		0	0
				- E			18		.9	4	8: -		3 <b>0</b> .	. 9	3.P.)	0	9.5		۵	<u>.</u>	

PowerTRONIC

4. Click on Refresh and Connect (Select the Appropriate COM Portin drop-down menu).

 Once connected the Map will be auto-read and then navigate to the Control Settings of the R-Tune V4 software.

Powertronic R-Tune v4	- 1.2.50														
≡(Рои	/er	TF	701		De Wa	vice conf it configu vice connec	figured su ring device cted.	uccessful	ly						
Map-1 : Fuel	Map-	1 : Fuel %	adjust (	Rpm v Lo	ad%)										
Map-1 : Spark		400	800	1200	1600	2000	2400	2800	3200	3600	4000	4500	5000	5500	600
Map-2 : Fuel	100	5	5	5	5	6	6	7	6	7	8	8	9	10	9
Map-2 : Spark	95	5	5	5	5	5	5	7	6	7	5	8	9	10	9
Quickshifter Settings			2											1.22	
Control Settings	90	-	5	5	,	0	0	7	0	10	8	*		10	
Factory Settings	85	5	5	5	5	6	6	7	6	7	8	8	9	10	9
Index Maps	80	5	5	5	5	6	6	7	6	7	8	8	.0	10	9
Dials															
Realtime Graphs	75	1	4	4	4	5	5	6	5	6	7	7	8	9	8
Device Information	70	4	4	4	4	5	5	6	5	6	7	7	8	9	8
	65	3	а	3	з	4	4	5	4	5	6	6	7	8	7
	60	2	2	2	z	3	3	4	3	4	5	5	5	7	5
	55		1	1	1	2	z	3	z	3	4	4	5	5	5



- PowerTRONIC
- 6. Select Throttle Position/Injection Pulse Width from the Load Channel Input from the drop-down.

Note: Injection Pulse Width has to be selected if the PowerTRONIC Harness doesn't come with a TPS Connector and follow the steps (Eg: RE Himalayan 2021 without choke/Bi-starter)

E Powe		i <mark>ing live data.</mark> e data to device - (DONE) a nament			Connected	CON CON	A13 - USE
Map-1 : Fuel		Control	Settings 1			Live d	lata
Map-1 : Spark	Load	setting		Rev Extend and Limit	ter Settings	Engine RPM	0
Map-2 : Fuel	Load Input Channel	Load from TPS	Rev Limit RPM		8200	Load % bar	No.
Map-2 : Spark		- > Throttle position			Rev Limit Disabled 🛛 👻	Tps Volt (v)	0.524
Quickshifter Settings	Load (	allon Injection pulse width			Inactive	Load %	T
Control Settings		Inactive: click botton to start	Con Sync Status		No Sync	Map Number	Map-1
actory Settings			Rev Extend Type		Disabled 🔫	QS Logical Status	Institut
ndex Maps		0	Revistend Status		inactive	Load Input Channel	Load from TPS
Realtime Graphs		0.524	Rev Extend Load		10	Load Calibration Status	inactive: click butto
Device Information		0.742	Fuel Chifer		n	Rev Limit Status	Inactive
	Load Tpr Raw Max	3.029	Fuel Chillef Corr		Ū	Ckp Sync Status	No Sync
		0	Chp Rpm Chp Toeth Gap %		1	RevExtend Status	inactive
	Load Inj Per Raw Min	2.5			ö		
			Syne-counter		n		
			Laurence				
Spi	ark Input Status	Fuel Duty		Injecto	or Input Status		
	inactive	nj-1 Duty Cycle		inj-1 Status	inactive		
	inactive			Inj-2 Status	inactive		
	Inactive	nj-3 Duty Cycle		inj-3 Status	Inactive		
pk-4 Status	inactive	nj-4 Duty Cycle		inj-4 Status-	Inactive		

7. Click on Load Calibration. Follow the on-screen instructions in Load Calibration Status, Refer Figures below.

Powertronic R-Tane v4	- 12.79		
	Perice configu Wait. configuring Device connected	ared successfully device	
Map-1 : Fuel		Contr	ol Settings 1
Map-1 : Spark	Load setting		Rev Exten
Map-2 : Fuel	Load Input Channel	Load from TPS	Rev Limit RPM
Map-2 : Spark	Load Channel Input	Throttle position	- Rev L mit Type
Quickshifter Settin <mark>g</mark> s	Load Calibration		Rev L mit Status
Control Settings	Observe the Dialogue Box Message for steps to	Inactive: click button to start	Ckp Sync Status
Factory Settings	follow		Part I Hand Turns
Index Maps	Load % bar		nev i ttenu type
Dials		0	RevExtend Status
Realtime Graphs	Tps Volt (v)	0.506	Rev Extend Load %
Device Information	Load Tps Raw Min	0.599	Fuel Ch1Ref
	Load Tps Raw Max	0.599	Fuel Ch1Ref Corr
	Inj Pw Raw	0	Ckp Rpm
	Load Inj Pw Raw Min	4.783	Ckp Tooth Gap %





8. Click on Load Calibration and proceed as per the instruction displayed in the Dialogue box (This Step is recording the Zero Throttle Position)

Note: Let the Bike Idle for 10 seconds before clicking on Load Calibration again to proceed to the next step.

🛃 Powertronic R-Tune v4	- 1.2.79	
	/erTRONC Load calibrat Resuming live d Live data pause	t <mark>ion event</mark> lata. d.
Map-1 : Fuel		Control Settin
Map-1 : Spark	Load setting	
Map-2 : Fuel	Load Input Channel	Load from TPS Rev
Map-2 : Spark	Load Channel Input	Throttle position 👻 🤻 🗤
Quickshifter Settings	Load Calibratio	n Revi
Control Settings	Load Calibration Status	Active: Stay at idling, then click button
Factory Settings	load & bar Observe the Dialogue Box	Rev
Index Maps	Message for steps to	
Dials	Load % follow	0 RevE
Realtime Graphs	Tps Volt (v)	0.522 Kev

9. Click on Load Calibration and proceed as per the instruction displayed in the Dialogue box.

(This Step is recording the Full Throttle Position)

**Note: Wide open the throttle once** to complete the process then click on **Load Calibration** to complete the process

Powertronic R-Tune v4 -	- 1.2.79	
= Pow	Contraction (Contraction)	ation event data. sed.
Map-1 : Fuel		Control Settin
Map-1 : Spark	Load settin	ng
Map-2 : Fuel	Load Input Channel	Load from TPS Rev
Map-2 : Spark	Load Channel Input	Throttle position 🗸 🖡 ev 1
Quickshifter Settings	Load Calibrati	ion Rev I
Control Settings	Load Calibration Status	Active: Go full load and then zero, then click
Factory Settings	Lord % has Observe the Dialogue Box	
Index Maps	Message for steps to	
Dials	Load % follow	100 <b>FevE</b>
Realtime Graphs	Tps Volt (v)	0.521 Rev





10. Once the Process is complete Monitor the Load TPS Raw Min and Load TPS Raw Max Values,



Note: Load TPS Raw Min and Load TPS Raw Max Values have to be different

11. Once the Above mentioned steps are complete please click on **Burn to save the change done to the ECU**, **Note:** Please Make sure the **Ignition Key is Turned Off before clicking on Burn** 

= Pou		Device config	ured successfully			Device configured accounting .		M11 - USB
		Device connected	a deserce L					۲
Map-1 : Fuel			Contro	ol Settings 1			Live d	ata
Map-1 : Spark		Load setting	2		Bey Extend and Limiter	r Settings	Engine RPM	
Map-2 : Fael	Listit lepot thankel		Load from TPS	Rev Linds RPM		12030		
Map-2 : Spark			Throthic position	- Restlimit Type		Spark Cut Only 🔫		0.462
Quickshifter Settings		Load Calibration		Rev Limit Status		inactive	Land B.	0
Control Settings			mactive: slick button to start	Ckp Sync Status		Na Sync	Map Number	Map-1
Factory Settings	Load 5-thir			Revelation Type-		Enabled •	OS Lunical Status	Inaction
Index Maps			0	Restated States		inactiva		Load from TPS
Dials			0.402	Rev Catend Load IV				Interface of the house of the second
Device Information			4.222	Funt Chillet		0	Real and the second	interest cick becau to start
				Total Chilles Con			And a state of the state of the	ingening.
6	Long the man was t		1001				CKESSIC SHEET	No sync
				Chi hire		×		( Jeartine )
			3.919	Ckp Tools Gap %		0		
	Load by the Key Max.		7.682	Syne countar		0		
			Inactive	Rev Extend Valid CT				
				Load S-On				
				Remote .	200 C			
				Rpmc047	Flease	Before clicking on BURN	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
				Chair Tamiliy				
				A CONTRACTOR OF				
	Spark Input Status	- 10	Fuel Duty			-		
Sph-1-Status	Inactive	000-101						
Spile 2 Statui	Inactive	ings and	hary Cycle		BURN	Update Fir	mware 🤝	
Spe-2 Status	logetiva	001-201	liaty Cycla					
Spli-4 Status	inactive	Inj-44	buty Cycle:		Inte Stanus	Plactive		
						Select "Record" to start reco	rding or "Play" to open recorded file 🕨 🕨	BURN Update Firmwar